

GLANZEPOL

Glanzepol adhesives are specially formulated for installing Glanzepol polystyrene mouldings, ceiling rosettes and wall pilasters.

Bond to any porous surface (plaster, cement, gypsum, wood, polyurethane, painted surfaces etc.)

Can be used for fixing polystyrene, polyurethane and wooden interior decor.

 <p>Glanzepol Super Nails Adhesive</p> <p>High initial grab and final bond strength</p>	 <p>Glanzepol Adhesive + Joint Filler</p> <p>Fills in the joint gaps and conceals any imperfections</p>
---	---

Usage Instruction

i. Surface preparation

1. The moulding need to be bonded to dry, firm, clean, dust-, mould- and grease-free surfaces. All wallpaper, paint, loose plaster should be removed from both the wall and ceiling - try to test the moulding before commencing with the job.
2. It is recommended that within the marked off area where the moulding is to be fitted, the substrate (both wall and ceiling) is first roughened (sharp knife- criss-cross scratches or sanding) to provide a key for the adhesive. Use a clean brush to remove any dust.
3. Recommended premise humidity during the installation shall be within 40-80%.



+35°C +8°C **installation**

+90°C -20°C **long term usage**

ii. Application

1. Glanzepol adhesives are a ready-to-use paste and must not be adulterated by the addition of water or any other substance. Shake well before use.
2. Insert the **GLANZEPOL SUPER NAILS ADHESIVE** cartridge into adhesive gun.
3. Evenly spread sufficient adhesive beads along the top and bottom edges of the moulding where it will make contact with both the wall and ceiling.
4. Press the moulding into place within 10 minutes after adhesive application.
Gently apply pressure along the length of the cornice to ensure that the adhesive makes full contact with all surfaces. If the ceiling or wall is not straight, do not push hard where there is a large gap.
5. When installing long sections of mouldings, it may begin to sag before the adhesive has set. If this occurs, insert one or two galvanized nails into the wall under the bottom edge of the moulding for temporarily support - once the adhesive has set, the nails can be removed and the holes filled.

6. As each successive length is installed, each piece will have at least one joint, apply a small amount of **GLANZEPOL ADHESIVE + JOINT FILLER** at the joint end so that the lengths are bonded end to end.

7. Any excess adhesive squeezed out during the installation should be wiped off with a caulking tool and a damp sponge or cloth.

8. Glanzepol adhesives are fully cured in 24 hours. Once cured can be sanded and painted over.

Cleaning

Clean equipment with water before adhesive dries. Dried adhesive can be manually brushed or scraped using hot water.

Storage stability

GLANZEPOL ADHESIVES have a shelf life of at least 24 months if stored in a cool (5°C ...25°C), dry place in its original moisture-tight container.

If the material is kept beyond the recommended shelf life, it is not necessarily unusable, but a check should be performed to observe whether the product is still workable, apply-able and uncured.

Safety instructions

Although **GLANZEPOL ADHESIVES** are non-toxic, safe handling practices should still be implemented to avoid irritating sensitive skin. Wear rubber gloves to avoid direct contact with skin. Avoid contact with eyes. In the event of skin contamination, rinse thoroughly with cold water. Seek medical assistance if irritation or discomfort persists.

Cured acrylic sealant can be handled without any health risk

Keep GLANZEPOL ADHESIVES out of reach of children!

Refer to our Material Safety Data Sheets for further toxicological information.